

# femooi

## Ada Pro<sup>TM</sup>

产品使用说明书



Thank you and congratulations for purchasing the Femooi Ada Pro™ device. Before enjoying all the benefits of this device, please take a few moments to read the instructions in this manual carefully.

## About Ada Pro™

Ada Pro™ is about to become your most effective facial cleansing care assistant, bringing you skin cleansing and anti-wrinkle care to help you rejuvenate your natural, fresh and radiant skin. Below we show you a simple and comprehensive overview of the functions of your new Ada Pro™.



The extremely high-quality silicon material of the brush has been carefully selected because of its skin-friendly and food-grade properties and will help you by tending to your delicate skin.

---



The high-tech silicone material is easy to dry, damp-proof and has anti-bacterial properties. Therefore, it is not necessary to replace the brush which makes this product a sustainable choice, contributing to a better environment.

---



The delicate and gentle silicone bristles on the brush provide a soft touch. Moreover, the extra-long bristles, combined with the extra-large surface of the brush and the gradually changing angle of the bristles make for the perfect combination of comfort and cleanliness.

---



IntelliTemp™ integrates heating and cooling functions to contribute to a more efficient facial cleansing experience and will simultaneously enhance the smoothness and elasticity of the skin. Further, it can help with fully absorbing skin-care products, and providing a calming effect on the skin when you need it.

---



The unique innovative eye-care function can help to brighten your eyes and makes you look younger. It can gently warm and cool the eyes to promote blood circulation and relieves dark circles and puffiness around the eyes.

---



Three adjustable cleansing intensities (up to 8000 movements per minute) make it possible to clean deep inside the pores, removing all types of stubborn dirt in the skin such as grease, dead skin and make-up leftovers. This results in a thorough cleansing of the skin suitable for a variety of facial cleansing needs.

---



The V-SMART™ pulse setting combined with the carefully placed massage surface create a comfortable and effective skin lifting effect and a relaxing and enjoyable massage. This will help the appearance of fine lines, smoothen wrinkles, and make the skin firmer and younger.

---





The wireless charging is simple and easy to operate, the unique design of the wireless charging dock guarantees a clean and dry brush.

---






Originated in the Netherlands, this product is designed and crafted with the goal to create a simple, modern, and feminine appearance. The size and weight of the product are carefully chosen to be suitable for the female needs and will bring you an extraordinary and pleasant experience.

# Device:






- ① Deep Cleansing bristles
- ② Indicator light
- ③ Operation interface
- ④ Dual-temp head
- ⑤ Massage surface
- ⑥ Wireless charging receiver surface

## Wireless charging dock:




- ⑦ Wireless charging transmitter surface
- ⑧ Opening for water drainage
- ⑨ Power port

## Device Placement:



## Other items:



Power adapter



Storage bag



Manual  
(including warranty card)

## Usage:

The unique silicone cleansing bristles of Ada Pro™ can be used with all types of skin and provides targeted solutions for different cleansing areas on the face. The IntelliTemp™ heating and cooling functions can contribute to a better skincare. It is recommended to use Ada Pro™ every day for a simple cleansing in the morning and a complete cleansing routine in the evening. The usage frequency of each function can be adjusted depending on your skin condition. Before you start, please study the following important information:

- Charge your Ada Pro™ until the battery is fully charged. Please consult the “Charging” section in this manual for more information.
- Before initial use, unlock the Ada Pro™ by pressing the cleansing button and massage button simultaneously ( a short vibration and one flash of the indicator light will be given when the product is unlocked).
- If you have a sensitive skin or skin allergies, please test the product first on the back of your hand to confirm that no abnormalities occur.
- If you notice any redness, swelling, itch or other abnormalities on your skin, discontinue use immediately and consult a physician.
- We do not recommend sharing your Ada Pro with anyone else or using Ada Pro™ on other areas than the face.

## Description of modes:

1. Press the “Heating button” to start the heating mode of Ada Pro™ . The indicator light will continuously fade from dark to bright to indicate the mode has started, and the dual-temp head will begin to heat-up. Press the button again to disable the heating function.
2. Press the “Cleansing button” to start the cleansing mode of Ada Pro™. The indicator light will flash quickly to indicate the cleansing mode has started. Press the button again within 10 seconds to adjust the cleansing intensity and choose between a total of three intensity settings. Each time a new intensity is selected, the indicator lighted flashes to confirm the choice. After using an intensity setting for more than 10 seconds, the intensity setting will be stored as preferred intensity using the intelligent memory function. When pressing the “Cleansing button” again, the cleansing mode will be disabled. Upon next usage, the cleansing mode will automatically start with the stored preferred intensity setting.
3. Press the “Massage button” to start the massage mode of Ada Pro™ . The indicator light flashes once to indicate the mode has started. Press the button again to disable the massage mode.
4. Press the “Cooling button” to start the cooling mode of Ada Pro™ . The indicator light will continuously fade from bright to dark to indicate the mode has started. Press the button again to disable the cooling mode.
5. Simultaneously press the “Cleansing button” and the “Massage button” for 2 seconds to enable or disable the self-lock mode. The self-lock mode is confirmed through a short vibration and one flash of the indicator light. The device will also confirm disabling of the self-lock feature through a short vibration and one flash of the indicator light.

## Description of modes:

- \* When starting the heating or cooling mode it will be enabled for 1.5 minutes. After the time has passed, the device will vibrate shortly as a reminder and disable the mode automatically. If you would like to continue to use the heating or cooling mode, you can enable the mode by pressing the button again.

- \* When the Ada Pro™ is running low on battery, the heating and cooling modes will be automatically disabled. For further details, please consult the “Charging” section in this manual.
- \* Do not switch too fast between heating and cooling modes.
- \* Please turn off and restart the cleansing mode to reset the preferred intensity setting in the intelligent memory function. This action will enable a new 10 seconds intensity adjustment time. During the intensity adjustment time, the “Cleansing button” can be pressed to cycle through the four settings of “LOW→MID→HIGH→OFF.”

## Detailed Steps:

### Facial Cleansing & Care

---

Ada Pro™ Cleansing mode 



STEP1: Dampen your face and apply your regular cleansing product, make Ada Pro™ slightly wet.



STEP2: Press the “Cleansing button” and begin to cleanse your face.

Press the button again within 10 seconds to adjust the intensity setting of the cleansing mode. For details, please consult the “Description of modes” section in this manual.

STEP3: Every 15 seconds a short pause will remind you to cleanse the next area. It is recommended that you cleanse the following four areas with Ada Pro™ :

1. Left cheek and chin: Position the gradual bristles and use circular strokes to cleanse the cheek and chin.
2. Right cheek and chin: Position the gradual bristles and use circular strokes to cleanse the cheek and chin.
3. Forehead: Starting from the center of your forehead, position the gradual bristles and use gentle outward strokes to cleanse the forehead on both sides.
4. Nose: When cleansing your nose, apply the deep cleansing bristles and gently wipe the long cleansing brushes up and down on one side, then repeat the cleansing on the other side of the nose.



After 1 minute, the device will notify you that the cleansing routine has been finalized through 3 short pauses. Press the “Cleansing button” to disable the cleansing mode.

If you want to continue cleansing, you can continue to use it until the device automatically stops after 2 minutes. In the last minute, there will not be any notifications.



STEP4: After the cleansing process is completed, rinse and dry your face. Then, apply your favorite skincare products.

## Pay attention:

- \* Please take into consideration your personal skin condition to avoid overuse.
- \* Please be careful when cleansing the eye area, prevent direct contact between the device and the eyes or eyelids.
- \* It is recommended that people with sensitive skin start using the device cautiously. Maximum once or twice in a week, until the skin becomes accustomed to normal cleaning
- \* It is recommended that people with sensitive skin use this product with a gentle motion (see the additional illustration).



STEP1: Press the “Massage button” to start the massage mode. If you have a sensitive skin, it is possible to apply skincare products before use.



STEP2: Every 12 seconds there will be a short pause in the massage pulse to remind you to start massaging the next area. It is recommended that you use the unique V-SMART™ pulse of Ada Pro™ to massage the following five regions:

1. Forehead and eyebrows.
2. Area on the outer side of the left eye.
3. Areas around the smile lines and mouth area on the left side of your face.
4. Area on the outer side of the right eye.
5. Areas around the smile lines and mouth area on the right side of your face.

After 1 minute, 3 short pauses in the massage pulse will remind you that the recommended massage time has finished. Press the “Massage button” to disable the massage mode.

If you would like to continue the massage, you can continue to use it after the pause, but no more notifications will be given then. To prevent overuse, the device will automatically stop after 2 minutes.

## Note:

\* Please take into consideration your personal skin condition to avoid overuse.

## Eye Care

---

### Ada Pro™ Heating mode



STEP1: Press the “Heating button” to start the IntelliTemp™ heating mode.

Place the warm dual-temp head of the device on the skin around the eyes and gently massage to promote blood circulation and relieve dark circles. After 1.5 minutes, the device will give a notification to indicate that the heating mode is finished by a small vibration.

### Ada Pro™ Cooling mode



STEP1: Press the “Cooling button” to start the IntelliTemp™ cooling mode.

Place the cold dual-temp head of the device on and gently massage the needed skin regions around the eyes, to help to effectively cool down skin and reduce eye puffiness. After 1.5 minutes, the device will notify that the cooling mode is finished by a small vibration.

TIP: The Heating Mode and Cooling Mode can help to relax and shrink the skin pores during the cleansing process, and achieve a more effective and thorough cleaning effect.

### Note:

\* After using the cooling mode, it is normal that the device feels slightly warm. Immediately stop using the cooling if the device is overheating and extremely hot.

### Warning:

\* If you have any discomfort when using Ada Pro™, discontinue use immediately and consult a physician.

# Maintenance:

For optimum usage and safety, please take good care of your Ada Pro™ and consider the following points:

- Do not switch rapidly between the heating and cooling modes, as this can reduce the effectiveness of the functions.
- Do not switch frequently between the heating and cooling modes, to avoid shortening the life-span of the dual-temp head.
- Do not use essential oils to protect the silicone surface.
- After each use, thoroughly clean the device using neutral detergent and clean water. After cleaning the device, rinse the device with warm water and wipe it dry using a soft cloth or towel.
- Wipe the wireless charging dock clean using a soft, damp cloth.
- Do not use any clay or silicon based cleanser, or any other granular skincare products such as exfoliating creams or scrubs in combination with Ada Pro™. These substances may damage the soft bristles on the cleansing surface.
- Do not clean the device with alcohol, benzene or acetone-based cleaning products, as these may irritate the skin.
- Do not place Ada Pro™ in acidic or alkaline liquids.
- Do not put the Ada Pro™ in a dishwasher, microwave oven or high-pressure cooker as this could result in accidents or injuries.
- Avoid direct sunlight and do not expose the device to extreme heat or boiling water.
- Keep the device out of reach from children and do not allow them to use the device.
- Do not use the device when charging.
- Turn off all functions before enabling the self-lock mode.
- Charge your Ada Pro™ when the battery is low to extend the battery life.
- Only use the included original Ada Pro™ wireless charging dock and power cord.
- Do not disassemble, modify or repair the product.
- Only use the device following the specific instructions mentioned in this manual.

## About Power and Charging :

Your Ada Pro™ can be charged wirelessly by using the included wireless charging dock. It will take 5 hours to charge the device from an empty battery to fully charged.

- Plug the DC plug on one end of the charging cord into the power port in the back of the wireless charging dock. Plug the other end of the charging cord into the power outlet.
- Place the Ada Pro™ upright in the wireless charging dock, consult the image in the “Device Placement” section for instructions. When aligned correctly the indicator light of the device will blink in a breathing rhythm to indicate that the battery is charging normally. When the charging is finished, the indicator light will change from a breathing rhythm to constantly being on.
- When the battery is low, the indicator light will flash for 10 seconds to remind you that the cleansing and massage modes are available, however, the heating and cooling modes will not work. The device will give this reminder until the battery’s power is completely exhausted.

The following illustrates the power consumption of each function:

Heating mode/time	8%	Fully charged → can be used alone around 10 times → low power → charge
Cleansing mode/time	1%	Fully charged → can be used alone around 100 times → no power → charge
Massage mode/time	1%	Fully charged → can be used alone around 100 times → no power → charge
Cooling mode/time	8%	Fully charged → can be used alone around 10 times → low power → charge
Standby/day	0.2%	Fully charged → Stand-by for 180 days → no power → charge

### Note:

- \* The Heating mode and Cooling mode are more power-consuming and frequent use will result in the low-power mode.
- \* When the battery is low, please charge the device in time to prolong battery life.

### Warning:

- \* Do not immerse the device and wireless charging dock into water or other liquids for a long duration.
- \* Before charging, make sure that the wireless charging dock and the power cable connector are dry. Also confirm that the power voltage from the outlet matches the indicated required power voltage of the device.
- \* Do not charge the device in a location where there is a risk of flooding.

# Frequently Asked Questions

Following is a list of the most commonly asked questions about Ada Pro™. If you are unable to find the answer to your question on this list, please call our customer service hotline for more information.

## The light indicator of Ada Pro™ does not flash anymore when the charger is connected?

- The battery is completely exhausted and requires to be charged for a few minutes before it shows the light indicator again.
- The device is not placed vertically into the wireless charging dock.
- The DC charging plug or the power plug are not connected.

## Ada Pro™ doesn't respond when the buttons are pressed?

- The self-lock mode is enabled, simultaneously press the "Cleansing button" and the "Massage button" for 2 seconds to disable the self-lock mode.
- The internal temperature of the device too high, and the device entered the temperature protection mode. Before trying again, please place the device aside for a period of time until the temperature dropped back to room temperature.
- The battery is empty, please charge the device.
- The microprocessor encountered a brief operational error. Please connect the charging cable and place the device on the wireless charging dock to reset the device to its initial state.

## After initiating the heating or cooling mode, the dual-temp head doesn't change its temperature?

- The battery level is low or exhausted, please charge the battery.
- The microprocessor encountered a brief operational error. Please connect the charging cable and place the device on the wireless charging dock to reset the device to its initial state.
- If the outside temperature is extremely hot or cold, it may affect the heating or cooling functions of the product. It is recommended to use the device at a suitable temperature (between 5°C and 28°C).

## The silicone bristles of Ada Pro™ have degraded to a sticky or bubbly texture?

- Discontinue use immediately. Although the silicone of Ada Pro™ is highly durable, it may degrade under certain conditions of non-normal use. Consult this manual's "Maintenance" section for how to prevent this.

## Description of modes:

1. Press the "Heating button" to start the heating mode of Ada Pro™. The indicator light will continuously fade from dark to bright to indicate the mode has started, and the dual-temp head will begin to heat-up. Press the button again to disable the heating function.

# Product specifications

Product Name: Femooi - Ada Pro Facial Cleansing Device

Product Type: FAP2.0

Product Material: Body-safe silicone, ABS and, body safe metal

Product color: Seashell white, ivory pink, frosted purple, rose red , azure blue, lemon yellow, knight black

Device Dimensions: 86 x 81 x 30 mm

Device Weight: 1105 gr

Base Dimensions: 70 x 73 x 43 mm

Base Weight: 50 grRated power: 110v-240v

Battery: Lithium-ion battery 500 mAh, 3.7 V

Charging time: 300 minutes

Standby time: 180 days

Frequency: 100 Hz

Noise level: up to 50 dB

Interface: 4 buttons, indicator light

Disclaimer: Product users at their own risk. Femooi and its distributors assume no responsibility or liability whatsoever for any bodily or non-physical injury or damage that occurs as a direct or indirect result of the use of the product. In addition, Femooi reserves the right to modify this manual and make changes to it at any time and is not obliged to notify any individual of these changes or changes. In case of dispute, the company reserves the right of final decision on the interpretation.

Note: Product or part specifications are subject to change without notice.

©2018 Femooi Technologies, All rights reserved

femooi (Netherlands): Femooi BV

Address: Fellenoord 130, Eindhoven, 5611 ZB, Netherlands

femooi (China): Ningbo Femooi Technologies Co., Ltd.

Address: Ningbo Jiangdong Road 375, Feng Ting Building, 8th floor

[www.lovefemooi.com](http://www.lovefemooi.com)